

SAVE THESE INSTRUCTIONS



Caution

- Do not fall asleep while using the product.
- Please do not use it when you are drunk or feel unwell.
- Please do not use this product to massage time for more than 30 minutes.
- Please don't use it when the cloth cover is broken.
- Please don't use it within one hour before or after having meals.
- If you have any symptoms of dizziness or fatigue, please stop the product immediately and rest for 10 minutes. If the symptoms gathered it may be affect the product normal operation, and even cause product failure, so recommended after the move, please the product under normal room temperature for one hour after using.

Warranty Permissions *

1. This warranty rights can't be transferred.
 2. This warranty is void if the warranty card is not filled, the warranty (warranty does not cover appearance, users only need to buy the freight back and forth).
 3. This warranty does not include the cost of labor or material.
 4. When asked the warranty service, please show the original proof of purchase and warranty card.
 5. This warranty does not apply to the other parts (parts are not included in the scope of warranty), such as the accessories (change labor costs and material costs).
 6. This warranty does not apply to lesions, staining, commercial, accidental and other residents of the user.
 7. This warranty does not apply to damage caused by the user's improper use, etc.
- a) All man-made damage, including abnormal operating conditions used, damage caused by the user's improper use, etc. b) Users privately disassemble, self-maintenance, modification or without maintenance, authorized third party dismantled, modification.
- c) After purchase due to damage caused by their own poor transport.
- d) Damage due to majeure factors (food, lightning, earthquake and so on).

3

Product Characteristics and use schematic *

- Product characteristics
- Beetle design, fashion and beautiful, light and portable.
 - Full foot massage, deep massage various points, clear the body.
 - Full foot massage, deep massage various points, clear the body.
 - Removable and washable cloth cover, keep cleaning.

Use schematic



Operator and Functions *

- Control Panel Functions
- Check whether have damage on the product
 - Check the placement is secure and comfortable

4

- (1) The scissor feet: Four independent control buttons -----control the massage function.
- (2) Front bottom center: Scrapping massage head -----achieve the foot arch or point massage, can heating.
- (3) Front bottom center: Rolling massage head -----achieve foot massage on point area.
- (4) Front bottom rear, top: Kneading massage head ----- achieve foot arch or point massage, can heating.
- (5) Surface inside arbig----- near to the instop, can arbig massager.
- (6) At the bottom of the front surface: removable and washable cloth cover.
- (7) At the bottom: Power plug location.
- (8) AC-Adapter.

Product specification *

Model	C170
Name	Beetle Foot Massager
Rated voltage	24V -----
Rated power input	45W
Rated time	15Min

7

Maintenance *

- a) Storage
- When not use the product, place it into the color box and places it in a safe, dry, ventilated, cool place.
 - Please don't use any harsh or abrasive cleaners to clean the product.
 - Please don't use any wax hanging products.
 - To avoid sharp points scraping the surface of product.
 - Please don't place the product in sunlight direct or high temperatures.

b) Cleaning

- Please pull out the plug before cleaning.
- Please use a soft cloth to clean the product. Do not use any harsh or abrasive cleaners such as benzene, or thinner to clean the product.

c) Maintenance

- Keep the product clean and away from high humidity places.
- If long time don't use this product, please use disgnod cover (products buy your own), prevent fall into dust.

8

Thanks for purchasing this product. Please read this manual instruction carefully before use. Please pay more attention to some important safety warning and keep this manual book properly for future use. The design and description of this product without any further notice. Please refer to the actual color of the product.

Safety Guidelines *

- A) To ensure safe and correct use of the product, please read this manual instruction carefully before operation.
- Please pull out the plug after use or before cleaning.
 - Please don't use the product on children or elderly people with skin irritation or burns.
 - Please don't allow children or physical and mental disabilities to use warm function, improper operation here may be life threatening.
 - Please don't use the product on people with heart disease, high blood pressure, overheat and cause fire, electric shock, or injury.
 - Please don't cover it using, to avoid motor overheating and cause a major fire.
 - If children or physical and mental disabilities use the product, need someone guidance and can be responsible for their safety.
 - Please don't use the product in a bathroom.
 - The following conditions occur do no use this product: the power line or power plug is damaged, do not operate properly, had fallen off the socket, the power cord is damaged or frayed, please contact the service center for inspection and maintenance.
 - Please don't use parts recommended by the non-manufacturer.
 - If you want to cut off the power, please after all of the operating is finished, please pull out the power plug from socket.
 - If you are in poor health, need treatment, or treatment, if went to hospital, please stop using this product.
 - After treatment, need the professional medical personnel to deal with it.

1

B) Environment for usage

- Please don't use in excessively humid or heavy-duty environment.
- Please don't use it when room temperature above 40 degrees.
- Please don't place it on an electric heater, near the stove or direct sunlight.

C) People who are not suitable to use the product

- If you have the following situation, consult your doctor before using.
 - Heart disease, high blood pressure, heart disease, cerebral arteriosclerosis, Patients with cerebral thrombosis
 - Patients with osteoporosis
 - Patients with osteoarthritis
 - Pregnant or menstruating women
 - With acute diseases patients
 - Minor
- If the patient has a heated surface. Persons insensitive to heat must be careful when using the appliance.

D) Switch Precautions

- Please don't use wet hand control switch.
- Please don't touch the power cord and the plug, if the cord or the plug is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience, knowledge or understanding of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

2

b) Method Of Usage

1 Plug the ac adapter into a power outlet. And connect dc output terminal to the massager. The power light flashing and then be in standby state.

2. Operation

Warm foot function: Control the foot heating function.
 1) Press the power button, the power light is on.
 2) Press the foot heating button, the power light is on, the foot heating function is started, the power light is on, the power light is on, the power light is on.

Spool button: control the air wave and speed.
 1) Press the spool button, the power light is on, the spool button is on, the power light is on, the power light is on.

Mode button: control the foot scraping function and the massage function.
 1) Press the mode button, the power light is on, the mode button is on, the power light is on, the power light is on.

Power button: control the air wave and speed.
 1) Press the power button, the power light is on, the power button is on, the power light is on, the power light is on.

Standby button: control the air wave and speed.
 1) Press the standby button, the power light is on, the standby button is on, the power light is on, the power light is on.

Stop button: control the air wave and speed.
 1) Press the stop button, the power light is on, the stop button is on, the power light is on, the power light is on.


Start button: control the air wave and speed.
 1) Press the start button, the power light is on, the start button is on, the power light is on, the power light is on.

Stop button: control the air wave and speed.
 1) Press the stop button, the power light is on, the stop button is on, the power light is on, the power light is on.

5

Abnormal situation	Possible Causes	Processing Method
Don't work	1. No power 2. Function keys not open	1. Connect the power or 2. Open the switch button
Low speed working	1. Lower off 2. Power off 3. Power on 4. Power off 5. Power on 6. Power off 7. Power on 8. Power off 9. Power on 10. Power off	1. Check the power cord 2. Check the power cord 3. Check the power cord 4. Check the power cord 5. Check the power cord 6. Check the power cord 7. Check the power cord 8. Check the power cord 9. Check the power cord 10. Check the power cord

The component of product *



6